

Worry-Free Chocolate Filling



Ingredients:

- 1/2 cup hot water
- 4 Tbsp cocoa powder
- 1 1/2 cups semi-sweet chocolate chips
- 2 cups heavy cream
- 3 Tbsp sugar

Directions:

- 1 Dissolve the cocoa powder in the hot water stirring frequently.
2. In the microwave or double boiler, melt the chocolate chips, just until smooth. If using the microwave, stir every 30 seconds until smooth.
3. Add the hot cocoa mixture to the melted chocolate chips and stir well to combine.
4. In a separate bowl, beat the heavy cream and sugar until it becomes stiff. It should be thick and not slide off your spoon.
5. Add the whipped cream mixture to the melted chocolate and mix until well combined.
6. Refrigerate until ready to use.

Enjoy!

